

TEKLYNX®

LABELVIEW™

VERSION 8

SETTING THE STANDARD



I N S T A L L A T I O N G U I D E



Installation Guide

The information in this manual is not binding and may be modified without prior notice.

Supply of the software described in this manual is subject to a user license. The software may not be used, copied or reproduced on any medium whatsoever, except in accordance with this license.

No portion of this manual may be copied, reproduced or transmitted by any means whatsoever, for purposes other than the personal use of the buyer, unless written permission is obtained from **Braton Groupe sarl**.

© 2009 **Braton Groupe sarl**.

All rights reserved.

TEKLYNX and its products are trademarks or registered trademarks of Braton Groupe sarl or its affiliated companies. All other brands and product names are the trademarks of their respective owners.

Rev – 190209

Welcome!

LABELVIEW label design and integration software provides an easy-to-use, user-friendly solution for printing bar code labels and tags to meet compliance standards in any industry.

This guide contains information on system requirements, product editions and configurations, and software protection methods. It also contains basic instructions for installing the LABELVIEW software, as well as information on other documentation resources you can reference.

System Requirements

Processor	Minimum: 600 MHz Pentium III-compatible or faster Recommended: 800 MHz or faster (minimum required for Windows Vista)
Operating System	Windows 2000 Professional with SP4 Windows 2000 Server with SP4 or later Windows XP with SP2 or later Windows Server 2003 Standard, Enterprise or Datacenter edition with SP1 or later Windows Vista Windows Server 2008
Memory	64 MB RAM with Windows 2000 (128 MB recommended) 128 MB RAM with Windows XP (256 MB recommended) 256 MB RAM with Windows Server 2003 (512 MB recommended) 512 MB RAM with Windows Vista (1 GB recommended) 512 MB RAM with Windows Server 2008 (2 GB recommended)
Hard Disk Space	Hard drive with at least 150 MB of available space
Display	Minimum: 800 x 600 High Color - 16 bit Recommended: 1024 x 768 True Color - 32 bit
Supporting Software	Microsoft Internet Explorer 6.0 SP1 or later Adobe Acrobat Reader 8.1

Additional Requirements	Parallel port if using a parallel key (hardware key) USB port if using a USB key (hardware key) Serial port if required by printer CD-ROM drive Mouse
--------------------------------	---

LABELVIEW Editions

LABELVIEW label design software is available in three editions — Basic, Pro, and Gold. (The edition and release number for your software are printed on a label located on the inside cover of the product CD case, as well as on the inside cover of the Quick Start Guide.) The following table provides an overview of the main features included in each edition.

FEATURE	Basic	Pro	Gold
General			
Print-only version		•	•
Network version			•
Keyless software activation	•	•	•
Citrix Server/Terminal Server support			(Network only)
Printer code converter			•
Label samples	•	•	•
MIL 129 and MIL 130L label samples			•
Unlimited number of fields per label	(25)	•	•
Hidden (unprintable) objects	•	•	•
Graphic formats import (bmp, pcx, jpg, tif, etc.)	•	•	•
Color support/Color graphic reduction	•	•	•
Graphical, native and custom bar code support	•	•	•
Automated Health Industry Bar Code (HIBC) configuration		•	•
2D bar code support		•	•
Multi-level password protection		•	•
Label specific passwords		•	•
Label previews	•	•	•
Multilingual support	•	•	•
Print to picture or to file		•	•
TextArt objects/RichTextField objects		•	•
Database			
Database Editor (DBF and ODBC data source)		•	•
OLE DB and ODBC support		•	•
Key field access to database records		•	•
Table view/print		•	•
File DSN support		•	•
Customized SQL queries/SQL Query Builder wizard			•

FEATURE	Basic	Pro	Gold
Variables			
Flexible date and time stamping	•	•	•
Variable graphic images		•	•
Global/shared serial files		•	•
Linked expressions		•	•
Increment per print job	•	•	•
Add an offset to date		•	•
User Input Fields			
Set input format	•	•	•
Minimum input length		•	•
Pick List data entry	•	•	•
Tools			
Pocket LABELVIEW support		(0 licenses)	(1 license)
Directly modify printer code with Job Modifier utility		•	•
LABELVIEW Symbol font (industry specific symbols)	•	•	•
View & customize reports generated from label log files (Log Viewer)			•
Automatically e-mail reports to track label stock usage (Media Tracking)			•
Automatic printing from a source database (DataWatch)			•
Print labels from serial device data (CommWatch)			•
Automatic printing based on a key field entered by an operator (Label Select)			•
Print labels automatically using simple instruction files (Command Files)			•
Visual Basic form builder			•
RFID Tag support			•
Programmability			
OLE Client (insert WordArt, spreadsheets, etc.)		•	•
OLE Automation			•
DDE (Dynamic Data Exchange)			•

Other LABELVIEW Configurations

LABELVIEW Full Design and RunTime Versions LABELVIEW is available in a Full Design version and in a RunTime (print only) version. The Full Design version is required in order to design, edit and save label design files. The RunTime version must be used in conjunction with a Full Design version. RunTime is limited to only opening and printing labels; you cannot add, move, delete or edit fields on a label.

LABELVIEW Single and Network Versions A LABELVIEW Single-User version is a stand-alone program that is intended to be installed on one PC. The LABELVIEW Network version is a multi-user license available only with the Gold edition.

Software Protection Methods

The method of software protection used depends on the type of LABELVIEW package you purchased — either a Software Key (an alphanumeric code) or a Hardware Key (a dongle).

Software Key Protection

The Software Key protection method requires simply that you enter an alphanumeric code to activate the software. The Software Key license is sometimes called a “keyless” license because it does not require an actual hardware key (dongle) to be connected to the PC. The encrypted Software Key code that you enter during installation is deciphered by the LABELVIEW software to determine settings such as licensing, release version, full design or print only version, and the edition information of the software that has been purchased.

Hardware Key Protection

If you have purchased a Hardware Key package, your software will include a hardware key device, also called a HASP (Hardware Against Software Piracy) key or dongle, that must be installed on the computer to run the software. The hardware key holds an encrypted code which is deciphered by the LABELVIEW software to determine settings such as licensing, release version, full design or print only version, and the edition information of the software that has been purchased.

Product Components

Your software can be delivered one of two ways: electronically via e-mail or on a CD-ROM in a box. If your software is delivered electronically, you receive an e-mail from TEKLYNX that includes the activation code and serial number, along with links to the TEKLYNX web site where you can download the software, manuals, and other documentation files.

If your software was shipped in a box, it is packaged with the following components:

- CD-ROM
- Documentation appropriate for the version you purchased
- Hardware key (if you purchased a Hardware Key version)



The edition and release number for your software are printed on a label located on the inside cover of the product CD case, as well as on the inside cover of the Quick Start Guide.

Installing LABELVIEW



The installation steps provided here cover a basic Full Install for a single user installation with Software Key protection. Detailed instructions for specific install scenarios (Hardware Key protection, Network installs, upgrades, etc.) can be found on your LABELVIEW CD by clicking the **Documents** button on the CD's opening screen or on the TEKLYNX web site.

► To install from electronic delivery:

Note

If you have already downloaded and installed the current LABELVIEW Demo, there is no need to install again. For Software Key versions, proceed to the section below on activating the software to convert the software from a trial version to a full product.

- 1 Open the e-mail message from TEKLYNX containing your software installation information. Click the hyperlink to download the software.
- 2 On the TEKLYNX Download Center page, click the **Download LABELVIEW** link. The File Download - Security Warning window opens.
- 3 Click **Save** to download the executable file to your computer. Be sure to note the location where the file is saved.
- 4 Double-click the executable file. If a security warning appears, click **Run**.
- 5 The **Choose Setup Language** window opens. Select the

desired language for the software interface screens, and then click **OK**.

The **Preparing to Install** screen will appear, followed by the welcome screen for the installation wizard.

- 6 Proceed with the installation process by following the on-screen instructions provided in the wizard.

► **To install from CD:**

Note

If you have already downloaded and installed the current LABELVIEW Demo, there is no need to install again. For Software Key versions, proceed to the section below on activating the software to convert the software from a trial version to a full product.

- 1 Insert the CD.

The CD's opening screen will appear. If the CD does not automatically open, use the Windows Run command to type the letter of the CD-ROM drive followed by CDSetup.exe (e.g., D:\CDSetup.exe) and press ENTER.

- 2 On the opening screen of the CD, click on **LABELVIEW**, and then click the **Install** button.
- 3 Select the desired language for the software interface screens, and then click **OK**.

The **Preparing to Install** screen will appear, followed by the welcome screen for the installation wizard.

- 4 Proceed with the installation process by following the on-screen instructions provided in the wizard.

► **To activate the software:**

- 1 Start LABELVIEW. A welcome screen appears displaying options to activate the software immediately or to try it for an evaluation period.
- 2 Click **Activate**, and then click **Next**.
- 3 Proceed with the activation process by following the on-screen instructions provided in the wizard.

Other Documentation Resources

Online Help

The LABELVIEW online Help system provides detailed information on using the program functions to create and run a tracking system. To access the Help in LABELVIEW, select **Help Topics** from the **Help** menu. For context-sensitive Help, press the F1 key or click the **Help** button located on many dialog boxes and wizard screens.

Product CD

In addition to any printed documentation that may be included with your product, you can find all available LABELVIEW documentation in PDF format on the product CD. The PDF documents can be viewed in Adobe Acrobat Reader and printed for easy reference.

To access the LABELVIEW documentation on the CD, click the **Documents** button available on the CD's opening screen.

If your software was delivered electronically, you can download the product documentation from the TEKLYNX web site.

Note

If you do not already have Acrobat Reader installed on your PC, it is available on the LABELVIEW CD.

Release Notes

The **Release Notes** file that installs with the software contains information about the most recent changes and updates to the software that were made after this guide was printed. This information supersedes what is contained in this guide. The Release Notes are also available for download from the TEKLYNX web site.

LABELVIEW on the Web

For the most current information on product updates, supported devices, technical support FAQs, product documentation, and other troubleshooting tips, please visit the LABELVIEW page on the Teklynx web site at <http://www.teklynx.com/LABELVIEW>.



United States	France	Germany	Singapore	China	Japan
1-414-535-6200	33-562-601-080	49-6103-30026-0	65-6477-7293	86-21-6100-6588	81-45-461-3603

For technical support contact your LABELVIEW software reseller. Online support is available free of charge at www.teklynx.com under SUPPORT. Copyright 2009 Braton Groupe sarl. All rights reserved. Printed in the USA 02/09. TEKLYNX and LABELVIEW are trademarks or registered trademarks of Braton Groupe sarl or its affiliated companies. All other brands and product names are trademarks of their respective owners.

www.teklynx.com

Microsoft
GOLD CERTIFIED
Partner